

REPLACING WOVEN HEADS

On Pintech pads with cylindrical foam

1. Remove all tension rods
2. Raise slightly one side of the old woven head
3. Using the other hand place one or two fingers on the foam at the point where the foam cylinder adheres to the old woven head
4. Holding the foam in place, slowly raise the old head making sure that there is no tension placed on the foam.
5. Install new head