

PINTECH USA

Accessory mounting instructions

Boom arms are more stable when mounted to vertical posts or legs



The cable is directly below the choke or second zone on cymbals

L-rods are more stable when mounted under the horizontal bar and away from the drummer



Cymbal springs take thicker cymbals when the "cap" is reversed



Stereo and dual zone items require a stereo cable (top)



The second zone of the cymbal works best when hit as shown

